

NOTES:

1. CROSSWALK AND TURN ARROWS SHALL BE HOT APPLIED THERMOPLASTIC OR APPROVED EQUAL, SEE DWGS. TE-6 AND TE-7.

